

# LOW FLOW FLEXI BUBBLER KIT 98501C

1. Remove panel to gain access to the bubbler from under the basin.
2. Remove bubbler by either unscrewing the nut under the basin and removing the tube from the quick connect fitting (see Figure A below) or by holding the existing bubbler nut and unscrewing bubbler.
3. Remove any fittings on the water tube to allow the new bubbler nipple to fit. The free end of the copper or poly tube must be 1/4" size with at least 3/4" of straight, round, and burr-free tube to insert into the bubbler quick connect fitting.
4. To install, hold the new bubbler in the desired position and tighten the nut from under basin.
5. Push the 1/4" tube into the quick connect fitting located in the bottom of the bubbler, approximately 3/4"
6. Operate the unit and check for leaks.
7. **CAUTION:** The regulator will need to be adjusted to prevent an oversize stream that will overshoot the basin and puddle water on the floor. Adjust the regulator stream so it is at the proper height (see cooler manual for proper height).
8. Re-assemble panel.

Figure A

## OPERATION OF QUICK CONNECT FITTINGS

